



BARRICADE CART ASSEMBLY

INSTRUCTIONS

Parts List

Part	Description	Quantity
A	Frame	1
B	Wheels	4
C	Upright Assembly	1
D	Stabilizing Bar	1
E	Arms	2
F	Arm Extensions	4
G	Handle	1
	6" Bolts & Nuts	28

Instructions

1. Position the wheels on the underside of the frame with the bolt holes in the wheel plate in line with the bolt holes in each corner of the frame.
2. Position the Upright Assembly on the upper side of the Frame in line with the bolt holes in each corner of the frame.
NOTE: Ensure holes in the Upright Assembly are aligned with the holes in the Frame AND the Wheels.
3. Attach the Wheels and Upright Assembly to the Frame with 16 x 6" bolts and nuts. Ensure the nuts are fastened tightly.
4. Attach the Stabilizing Bar to the Upright Assembly using 2 x 6" bolts and nuts.
Slide an Arm through the aperture on each of the uprights in the Upright Assembly and attach each Arm with 1 x 6" bolt and nut.
5. Slide and Arm Extension onto the ends of each arm and secure each extension with 1 x 6" bolt and nut
6. Attach the handle to the front of the frame with 4 x 6" bolts and nuts

IMPORTANT – Before use ensure all nuts are securely tightened

